

Application Instructions

Interior Ultra Proofer

Please note: Do not dilute or mix *Interior Ultra Proofer* with any other product! This would seriously impair the product performance. Test on an inconspicuous area first! Coverage will depend on age and condition of substrate.

- 1). Ensure that the surface is dry and free from grease.
- 2). Shake the container and unlock the nozzle.
- 3). Apply *Interior Ultra Proofer* in even sweeping motions at a distance of 10cm/4” until all of the surface has been evenly covered. N.B. Do not apply in direct sunlight as this will cause the *Interior Ultra Proofer* to dry out too quickly.
- 4). As each area is treated/covered with *Interior Ultra Proofer* it is then important to use a soft lint free/microfibre cloth to rub the *Interior Ultra Proofer* into the surface. In case of allergic reaction it is advisable to wear protective gloves during this process!
- 5). Allow the interior to dry.

Do's, don'ts & FAQ's available on www.renovointernational.com

IN CASE OF EYE CONTACT, FLUSH OUT IMMEDIATELY WITH WATER. IF PROBLEMS PERSIST, SEEK MEDICAL ADVICE. KEEP OUT OF THE REACH OF CHILDREN.

Store in a cool place out of direct sunlight. Do not store at a temperature below 0°C (32°F).

