

## Application Instructions

### Leather Reviver

**Please note: it is advisable to test on an inconspicuous area prior to use. It is advisable to wear protective gloves when using *Leather Reviver*.**

1). Use a clean, soft, lint free cloth to apply *Leather Reviver*. It is best to apply small amounts at a time and work the product into the leather with firm circular movements.

2). When a manageable area has been covered with *Leather Reviver*, use another comparable cloth to polish/buff the leather and remove any residual product that may remain on the surface.

Avoid allowing the *Leather Reviver* to come into contact with internal grills/speakers, carpets, head linings and any other areas from which it may prove difficult to remove this product.

**Do's, don'ts & FAQ's available on [www.renovointernational.com](http://www.renovointernational.com)**

IN CASE OF EYE CONTACT, FLUSH OUT IMMEDIATELY WITH WATER. IF PROBLEMS PERSIST, SEEK MEDICAL ADVICE. KEEP OUT OF THE REACH OF CHILDREN.

Store in a cool place out of direct sunlight. Do not store at a temperature below 0°C (32°F).

